JAI introduces new polarization camera in the Go Series. GO-5100MP-USB is ideal for plastics, glass, and other shiny materials

Property of the property of t


- Home
- News
- JAI introduces new polarization camera in the Go Series. GO-5100MP-USB is ideal for plastics, glass, and other shiny materials

By JAI | May 24, 2018


JAI has added a new model to its Go Series of small and versatile machine vision cameras. The GO-5100MP-USB is built around Sony's IMX250MZR polarized CMOS image sensor, offering 5.1 megapixels of total resolution and an innovative 4-way polarized filter design creating a range of possibilities for imaging and analysis of objects and materials in industrial applications.



The camera features a full resolution of 2464 x 2056 pixels with a 2/3" optical format and pixel sizes of 3.45 μ m x 3.45 μ m. The polarization capabilities are derived from the sensor's unique filter array, which consists of four separate polarizing filters – angled at 0°, 45°, 90°, and 135° - that have been arranged in a regular pattern across the sensor. Thus, each block of four pixels can be used as a calculation block to determine the angle and intensity of light reflecting from objects, as well as several other calculations.



The illustration above shows how the Sony IMX250MZR sensor is designed. The polarization capabilities are derived from the sensor's unique nano wire-grid arrays, which consists of four separate polarizing filters – angled at 0°, 45°, 90°, and 135° - that have been arranged in a regular pattern across the sensor.



The illustration above shows an example of how a nano wire-grid polarizer works. Due to electric field behavior, all light waves that hit the horizontal wire-grid will be blocked and/or reflected by the grid, except for light waves perpendicular to the alignment of the grid.

The use of polarization filters can not only mitigate reflections and hot spots, particularly when inspecting plastics, glass, and other shiny materials, but can also enable analysis of material thickness, stress points, and other potential defects not detectable using standard machine vision techniques.

In total 5.1 Megapixel 90° 90° 90° 2056 pixels.... 90° 90° 90° One pixel 2464 pixels.... 45° 135° 1.27 Megapixel

The chip delivers four images in which polarized light is blocked in a specific angle in every image. Each image is a $\frac{1}{4}$ (1.27 megapixels) of the total chip resolution.

The GO-5100MP-USB is equipped with a USB3 Vision interface enabling it to provide full resolution, 8-bit output at up to 74 frames per second. 10-bit and 12-bit output is also supported.

Other camera features include both single-ROI and multi-ROI functions, shading compensation, and gamma correction. The main camera body is a compact 29 x 29 x 41.5 mm, with a lens mount supporting standard C-mount lenses. Like other Go Series cameras, it is built to high standards for shock (80G) and vibration (10G) to enable it to perform in industrial environments with an MTBF rating of more than 150,000 hours. Full production is schedule to begin in November.


A few application examples:

Download datasheet

Internal material stress "frozen-in" during manufacturing of glass and plastics can be problematic. Inspection systems

1232 pixels

for bottles, eyewear, window glass, etc. can benefit from GO-5100MP-USB polarization camera.









The GO-5100MP-USB can eliminate unwanted glare and reflections from car windshields making it possible to better see inside the cabin for better facial recognition and to provide better evidence in the case of seatbelt or mobile phone use violations.

Scratches, dents and inclusions in finished glass are often easier to detect by analyzing with polarized light. Inspection systems for window glass, bottles, eyewear, and lenses can benefit from the GO-5100MP-USB camera.

Polarized imaging can be used to inspect the quality of spray painted surfaces in industries such as automotive and furniture, looking for unwanted scratches, dust spots or uneven paint layers.

Topics:AREA SCAN CAMERA NEWS