







GTK-KIT-VS-14ST Kit Components

#	Item Description	Part Number
1	<ul style="list-style-type: none"> • USB 3.0 Camera Cable • Ring Light, White 	<ul style="list-style-type: none"> • GTK-USB3-Cable • GTK-Ring-Light
2	<ul style="list-style-type: none"> • 2 x 2 Square Backlight, Red 	<ul style="list-style-type: none"> • GTK-Backlight
3	<ul style="list-style-type: none"> • 5mm Lens 	<ul style="list-style-type: none"> • GTK-5mm-Lens
4a – 4b	<ul style="list-style-type: none"> • Desk Top Copy Stand 	<ul style="list-style-type: none"> • GTK-Desktop-Stand
5	<ul style="list-style-type: none"> • USB 3.0 Camera with Mounting Bracket • 0.5/1/5/10/20/40mm Extension Tube Kit • 25.5 - 27mm Step-Up-Ring • Hex Keys 	<ul style="list-style-type: none"> • GTK-1300-30um • GTK-Ext-Tube • GTK-Step-Up-Ring • GTK-Hex-Kit
6	<ul style="list-style-type: none"> • 27mm Linear Polarizer • 12.5mm Lens 	<ul style="list-style-type: none"> • GTK-Polarizer-27 • GTK-12.5mm-Lens
7a – 7b	<ul style="list-style-type: none"> • Color Spot Light with Mount and Charger 	<ul style="list-style-type: none"> • GTK-Color-Box-Light
8a – 8b	<ul style="list-style-type: none"> • Ring Light/Back Light Power Supply and Cable 	<ul style="list-style-type: none"> • GTK-Desktop-AC-Adapter
9	<ul style="list-style-type: none"> • Calibration Target 	<ul style="list-style-type: none"> • GTK-Cal-02-05-MM
10	<ul style="list-style-type: none"> • Color Target for Exercises 	<ul style="list-style-type: none"> • GTK-EXC-TGT01-v1.0
11	<ul style="list-style-type: none"> • Plastic Protective Storage Case 19" x 14" x 6" 	<ul style="list-style-type: none"> • GTK-Storage-Case



GTK-KIT-VS-14ST Kit Assembly Procedure



Step	Description	Picture
1	Assemble the Desk Top Copy Stand (4a – 4b) using the wing nut.	
2	Attach the camera (5) to the top of the pole (4a) on the Desk Top Copy Stand as shown.	
3	Attach the Ring Light (1) to the camera mounting bracket (5) as shown.	
4	Attach the Color Spot Light (7a) to the Ring Light (1).	
5	Connect the Ring Light/Back Light power supply provided (8a – 8b) to the Ring Light (1).	
6	Plug the Color Spot Light charger (7b) into the Color Spot Light (7a).	
7	Connect the camera to the computer using the USB 3.0 cable (1).	